CARNIVAL

DMX512

LINKABLE

STAND ALONE

Marvelous Sound Activation



LED-7875

User Guide

Please read the instruction carefully before use

Contents

1. Safety Instructions 2

2. Technical Specifications 3

3. Technical Specifications 4

3.1 Control Panel 4

3.2 Main Function 5

4. How To Control The Fixture 8

4.1 Master/Slave Built In Preprogrammed Function 8

4.2. Easy Controller (by CA-8) 9

4.3 DMX Controller 9

5. DMX512 Configuration 10

6. DMX512 Connections 11

7. Troubleshooting 12

8. Cleaning And Maintenance 13

1. Safety Instructions

WARNING

Please read the instructions carefully which includes important information about the installation, operation and maintenance.

- Please keep this User Manual for future consultation. If you sell the fixture to another user, be sure that they also receive this instruction booklet.
- Unpack and check carefully there is no transportation damage before using the fixture.
- It's important to ground the yellow/green conductor to earth in order to avoid electric shock.
- Disconnect main power before servicing and maintenance.
- Maximum ambient temperature is Ta : 40℃. Don't operate it where the temperature is higher than this.
- In the event of serious operating problem, stop using the fixture immediately. Never try to repair the fixture by yourself. Repairs carried out by unskilled people can lead to damage or malfunction. Please contact the nearest authorized technical assistance center. Always use the same type spare parts.
- Do not connect the device to any dimmer pack.
- Do not touch any wire during operation and there might be a hazard of electric shock.
- To prevent or reduce the risk of electrical shock or fire, do not expose the fixture to rain or moisture.
- The housing must be replaced if they are visibly damaged.
- Do not look directly at the LED light beam while the fixture is on.
- There are no user serviceable parts inside the fixture. Do not open the housing or attempt any repairs by yourself. In the unlikely event your fixture may require service, please contact your nearest dealer.
- Due to the magnifying type lens, please keep the lens out of contact with direct sunlight. Direct sunlight can cause heat to build up inside of the unit, which will seriously damage unit.

For power supply, do not connect in series much more than 20 units, use another mains supply for next 20 units.

2. Technical Specifications

- 5 LED clusters, each equips with 64 high power LEDs
- DMX 512 control: 4 channels Function, Chase, Speed and Strobe
- Three operation modes: DMX, Master/Slave mode, Sound Active
- Great built-in programs under Master/Slave triggered by music
- Optional easy controller CA-8 for instant lighting shows
- LED display for easy navigation
- Ideal for discos, pubs, parties, clubs, Mobile DJs, etc

• **Voltage:** AC 100V-240V, 50/60Hz

• **Power consumption:** 40W

• **LED:** Total 320pcs,

Red 80pcs, Green 80pcs, Blue 80pcs, White 80pcs

• **Dimension:** 457 X 433 X 286mm

• **Weight:** 7.0kgs



3. Technical Specifications

3.1 Control Panel



1. Display: To show the various menus and the selected functions

LED:

2. DMX	On	DMX input present
3. MASTER	On	Master Mode
4. SLAVE	On	Slave Mode
5. SOUND	Flashing	Sound activation

Button:

6. MENU	To select the programming functions
7. DOWN	To go backward in the selected functions
8. UP	To go forward in the selected functions
9. ENTER	To confirm the selected functions

10. Only for remote control: By connect to the 1/4'' microphone jack to control the unit for Stand by, Function and Mode function.

11. DMX output: For DMX512 link, use 3-pin XLR plug cable to link the next unit.

12. DMX input: For DMX512 link, use 3/5-pin XLR plug cable to input DMX signal

13. Mains output: Connect to supply mains power for the next unit.

14. Mains input: Connect to supply mains power.

3.2 Main Function

To select any functions, press **MENU** button until the required one is shown on the display. Select the function by **ENTER** button and the display will blink. Use **DOWN** and **UP** button to change the mode. Once the required mode has been selected, press **ENTER** button to setup or it will automatically return to the main functions without any change after idling 10 seconds. Back to the functions without any change press **MENU** button.

The main functions are shown below:



DMX 512 Address Setting

Press the **MENU** button up to when the is shown on the display. Pressing **ENTER** button and the display will blink. Use **DOWN** and **UP** button to change the DMX 512 address. Once the address has been selected, press **ENTER** button to setup or automatically exit menu mode without any change after 10 seconds. Back to the previous functions without any change press **MENU** button.

Slave Mode

Press the **MENU** button up to when the is shown on the display. Pressing **ENTER** button, Use **DOWN** and **UP** button to select the (slave 1) or (Slave 2) mode. Once select, press the **ENTER** button to setup or automatically exit menu mode without any change after 10 seconds. To go back to the functions without any change press the **MENU** button

Show Mode

Press the **MENU** button up to when the is shown on the display. Pressing **ENTER** button, Use **DOWN** and **UP** button to select the (Random show) or (show 1) or (Show 2) or … or (show 12). Once select, press **ENTER** button to setup or automatically exit menu mode without any change after 10 seconds. To go back to the functions without any change press the **MENU** button

Color mode

Press the **MENU** button up to when the is shown on the display. Pressing **ENTER** button, Use **DOWN** and **UP** button to select the (color 1) … or (color 15). Once select, press **ENTER** button to setup or automatically exit menu mode without any change after 10 seconds. To go back to the functions without any change press the **MENU** button

Sound mode

Press the **MENU** button up to when the is shown on the display. Pressing **ENTER** button,

Use **DOWN** and **UP** button to select the on (sound on) or oFF (sound off). Pressing **ENTER** button, Use **DOWN** and **UP** button to select the SP 1 or SP 2 or SP 3 mode. Once select, press **ENTER** button to setup or automatically exit menu mode without any change after 10 seconds. To go back to the functions without any change press the **MENU** button

SEnS Sound sensitive

Press the **MENU** button up to when the SEnS is shown on the display. Pressing **ENTER** button, Use **DOWN** and **UP** button to change the number 0 … or 100 . Once select, press **ENTER** button to setup or automatically exit menu mode without any change after 10 seconds. To go back to the functions without any change press the **MENU** button

bLnd Blackout mode

Press the **MENU** button up to when the bLnd is shown on the display. Pressing **ENTER** button, Use **DOWN** and **UP** button to select the YES (blackout) or no (normal). Once select, press **ENTER** button to setup or automatically exit menu mode without any change after 10 seconds. To go back to the functions without any change press the **MENU** button

LEd LED display

Press the **MENU** button up to when the LEd is shown on the display. Pressing **ENTER** button and the display will blink. Use **DOWN** and **UP** button to select on (display on) or oFF(display off) mode. Once select, press **ENTER** button to setup or exit menu mode without any change after 10 seconds. Back to the functions without any change press **MENU** button again.

diSP Display Inverse

Press **MENU** button until diSP is blinking on the display. Use **DOWN** and **UP** button to select diSP (normal) or dSIP (inverse), press **ENTER** button to setup. Back to the functions without any change press **MENU** button.

Self-Test

Press the **MENU** button up to when the is blinking on the display. Pressing **ENTER** button and the unit will run the built-in programmer for self-test. To go back to the functions press the **MENU** button.

 **Fixture Hours**

Press the **MENU** button up to when the is blinking on the display. Pressing **ENTER** button and the display will show the number of working hours of the unit. To go back to the functions press the **MENU** button.

Software version

Press the **MENU** button up to when the is blinking on the display. Pressing **ENTER** button and the display will show the version of software of the unit. To go back to the functions press the **MENU** button again.

4. How To Control The Fixture

You can operate the unit in three ways:

1. By master/slave built-in preprogram function
2. By easy controller
3. By DMX controller

No need to turn the unit off when you change the DMX address, as new DMX address setting will be effected at once. Every time you turn the unit on, it will show “7875” on the display. After that the unit will be ready to receive DMX signal or run the built in programs.

4.1 Master/Slave Built In Preprogrammed Function

By linking the units in master/slave connection, the first unit will control the other units to give an automatic, sound activated, synchronized light show. This function is good when you want an instant show. You have to set the first unit in master mode and select (random show), (show 1) or …or (show 12) and speed. Its DMX input jack will have nothing

plugged into it, and its master LED will be constantly on and sound LED will flash to the music. The other units will have to select SL 1 (normal) or SL 2 (2 light show) mode, Their DMX cables plugged into the DMX input jacks (daisy chain) and the slave LED lights will be constantly on.

2-light show

In slave mode, SL 1 means the unit works as the master unit and SL 2 means 2-light show. In order to create a great light show, you can set SL 2 on the second unit to get contrast movement to each other, even if you have two units only.

4.2. Easy Controller (by CA-8)

The easy remote control is used only in master/slave mode. There is a terminator for connect the easy controller inside the fixture. By connecting the cable into DMX IN waterproof cable entry gland to the CA-8 terminator of the first fixture, you will find that the remote control on the first fixture will control all the other fixtures for Stand by, Function and Mode functions.



Blackout	Blackout the unit			
Function	1. White Strobe 2. Color Strobe 3. Sound White Strobe 4. Sound Color Strobe	Select Show (Show 1-12)	Select Color (Color 1-15)	Select Speed 1. Fast 2. Middle 3. Slow
Mode	Sound/Strobe (LED OFF)	Show (LED ON)	LED slow blinking	LED fast blinking

4.3 DMX Controller

Using universal DMX controller to control the units, you have to set DMX address from 1 to 512 channel so that the units can receive DMX signal.

Press the **MENU** button up to when the Addr is showing on the display. Pressing **ENTER** button

and the display will blink. Use **DOWN** and **UP** button to change the DMX512 address. Once the address has been selected, press and keep **ENTER** button pressed up to when the display stops blinking or storing automatically 8 seconds later. To go back to the functions without any change press the **MENU** button again. If you use please refer to the following diagram to address your DMX512 channel for the first 4⁄2 units.

4 channels:

5. DMX512 Configuration

DMX512 Configuration

Ch1	Ch2	Ch3	Ch4
Function	Chase	Speed	Strobe
250-255 Sound Active 130-249 Asynchronous Show 010-129 Synchronous Show 000-009 Off	235-255 Chase 12 214-234 Chase 11 192-213 Chase 10 171-191 Chase 9 150-170 Chase 8 128-149 Chase 7 107-127 Chase 6 086-106 Chase 5 064-085 Chase 4 043-063 Chase 3 022-042 Chase 2 000-021 Chase 1	255 Fast 0 Slow	255 ⚡⚡⚡ ⚡⚡ ⚡ 10 0-9 On

4 channels as a group, please refer to the DMX configuration of 4 channels to control the other channels.

6. DMX512 Connections

The DMX512 is widely used in intelligent lighting control, with a maximum of 512 channels.


COMMON
DMX INPUT
DMX +
DMX -
DMX OUTPUT
1
3
2
Termination reduces signal errors and to avoid signal transmission problems and interference. It is always advisable to connect a DMX terminal.
(Resistance 120 ohm 1/4W)between pin2(DMX-)and pin3(DMX+) of the last fixture.

1. Connect the fixture together in a “daisy chain” by XLR plug cable from the output of the fixture to the input of the next fixture. The cable cannot be branched or split to a “Y” cable. Inadequate or damaged cables, soldered joints or corroded connectors can easily distort the signal and shut down the system.
2. The DMX output and input connectors are pass-through to maintain the DMX circuit when one of the units’ power is disconnected.
3. At last fixture, the DMX cable has to be terminated with a terminator to reduce signal errors. Solder a 120-ohm 1⁄4W resistor between pin 2(DMX-) and pin 3(DMX+) into a 3-pin XLR-plug and plug it in the DMX-output of the last fixture.
4. Each lighting fixture needs to have an address set to receive the data sent by the controller. The address number is between 0-511 (usually 0 & 1 are equal to 1).
5. 3 pin XLR connectors are more popular than 5 pins XLR.

   3 pin XLR: Pin 1: GND, Pin 2: Negative signal (-), Pin 3: Positive signal (+)

   5 pin XLR: Pin 1: GND, Pin 2: Negative signal (-), Pin 3: Positive signal (+),

   Pin4⁄5: not used.

7. Troubleshooting

Following are a few common problems that may occur during operation. Here are some suggestions for easy troubleshooting:

A. The fixture does not work, no light

1. Check the connection of power and main fuse.
2. Measure the mains voltage on the main connector.

B. Not responding to DMX controller

1. DMX LED should be on. If not, check DMX connectors, cables to see if link properly.
2. If the DMX LED is on and no response to the channel, check the address settings and DMX polarity.
3. If you have intermittent DMX signal problems, check the pins on connectors or on PCB of the fixture or the previous one.
4. Try to use another DMX controller.
5. Check if the DMX cables run near or run alongside to high voltage cables that may cause damage or interference to DMX interface circuit.

C. Some fixtures don't respond to the easy controller

1. You may have a break in the DMX cabling. Check the LED for the response of the master/ slave mode signal.
2. Wrong DMX address in the fixture. Set the proper address.

D. No response to the sound

1. Make sure the fixture does not receive DMX signal.
2. Check microphone to see if it is good by tapping the microphone.

E. One of the channels is not working well

1. The stepper motor might be damaged or the cable connected to the PCB is broken.
2. The motor's drive IC on the PCB might be out of condition.

8. Cleaning And Maintenance

The cleaning of internal must be carried out periodically to optimize light output. Cleaning frequency depends on the environment in which the fixture operates: damp, smoky or particularly dirty surrounding can cause greater accumulation of dirt on the fixture’s optics.

- Clean with soft cloth using normal glass cleaning fluid.
- Always dry the parts carefully.
- Clean the external optics at least every 20 days. Clean the internal optics at least every 30/60 days.

Declaration of Conformity

We declare that our products (lighting equipments) comply with the following specification and bears CE mark in accordance with the provision of the Electromagnetic Compatibility (EMC) Directive 2004/108/EC.

EN55103-1: 2009 ; EN55103-2: 2009;
EN61000-3-2: 2006 + A1:2009 + A2:2009; EN61000-3-3: 2008.

&

Harmonized Standard

EN 60598-1:2008 + All:2009; EN 60598-2-17:1989 + A2:1991;
EN 62471:2008; EN 62493: 2010
Safety of household and similar electrical appliances
Part 1: General requirements

Innovation, Quality, Performance